

2018+ GMC TERRAIN NAV UPGRADE

Step 1: Pull off the side kick panel next to the seat. Just pull up on it by the seat it will pop out.



Step 2: Drop the glove box. Press in on both sides it will pop out then unhook the lever on the right side holding it from going too far. Just press the teeth together and release the lever.



Step 3: You will see your original HMI right there on the right. All the connectors have tabs you need to release with a tiny flat head screwdriver, so you can get the connectors out. Some are red and some white. Release all the connectors from the HMI.



Step 4: There are 2 screws that you need a size 7mm socket to get them out. This way you can move the bracket holding it in. Pull the carpet back and pull out the original HMI. There are 2 levers holding it from falling that you need to push back for it to come out.



Step 5: Install the new HMI we provided you with from Infotainment.com that has Navigation. Move the bracket back into place. Reconnect all the connectors. Put the 2 screws back into the holes. Re Install the glove box first pushing it into the bars at the bottom then connecting the rod that was holding it up then pushing it closed.

Step 6: Reinstall the kick panel back into place next to the seat going to the front.

Step 7: Install the Navigation SD Card we provided you into the SD Card slot under you screen in the USB Hub.



Step 8: Turn on the vehicle and you will see you have a Navigation Icon.

